



SCHEMATICS

CUSTOMER SERVICE
1-800-446-1071


Central Europe / Gas / Spirit (2013-2016)

[VIEW ALL](#)

MODEL #: 46613675 DESCRIPTION: SPIRIT E-320 ORIGINAL LP BLK W/GBS (2014) (CENTRAL EUROPE)

[Print Schematic](#)

Spirit® E320 Original
Additional Parts



08.13

SEQ	DESCRIPTION	PART#
A	Literature Kit, Spirit Original 210/220/320 w/GBS LP, C EU	48959
A	Literature Kit, Spirit 210/310/320 Original, export '14	57393
A	Assembly guide, Spirit 310/320 Original, C EU '14	58310
A	Assembly guide, Spirit 310/320 Original, C E '14	58330
A	Assembly guide, Spirit 310/320 Original, C E '14	58335

A	Brochure, Gourmet Barbecue System	56232
W	Hardware for side burner tray, Spirit '13	69897
W	Hardware, lid assembly, Spirit '13	69844
W	Hardware, ignition module assembly (Hardware bag D)	84686
W	Hardware, control panel assembly, Spirit 300 (Hardware bag J)	84691
W	Hardware kit, Spirit 320 Original, export '14	83651
W	Hardware for door assembly, Spirit 210/310/320, export '14	83656
W	Hardware, black side burner assembly	84694
W	Hardware, fixed table assembly (Hardware bag K)	84692
W	Hardware, caster assembly (Hardware bag A)	84683
W	Hardware, frame assembly (Hardware bag B)	84684
W	Hardware for fixed table, Spirit '13 (Hardware bag K)	69846
W	Hardware for mounting manifold, Spirit '13	69843
1	Bezel for thermometer, Spirit '13	69823
1	Thermometer, Q, Spirit, Charcoal '14, Export	74239
2	Logo, Spirit '13	69857
3	Lid assembly, Spirit 300, '13, black	69763
4	Warming rack, Spirit '09, 3 burner	91289
5	PECI cooking grate insert, Spirit w/GBS	64830
6	Lid for side burner, Spirit '13, black	69855
7	Hardware for fixed table, Spirit '13 (Hardware bag K)	69846
7	Side burner table, black, Spirit '13, export	69874
8	Side burner assembly tray, Spirit Original, '13	69882
8	Trivet for side burner, Spirit '13	69883
8	Flame ring for side burner, Spirit '13	69842
8	Hardware for side burner tray, Spirit '13	69897
8	Electronic igniter kit, Spirit 220-330	69851
9	Hardware, black side burner assembly	84694
9	Mounting plate for side burner, black	69858

10	Side burner knob, Spirit '13	69854
11	Burner tube kit, Spirit 300, '13, export	69786
11	Crossover tube, Spirit 300 series, '13	69898
12	Electrode for electronic ignition, Spirit '13	69794
12	Electronic igniter kit, Spirit 220-330	69851
13	Burner tube kit, Spirit 300, '13, export	69786
14	Cookbox, Spirit 300, '13	69783
14	Hardware for burner tubes/grease tray rails	62774
14	Grease tray rails, Spirit '13	69867
14	Hardware for mounting manifold, Spirit '13	69843
15	Aluminum drip pans - small	6415
16	Hardware, frame assembly (Hardware bag B)	84684
16	LHS panel assembly, Spirit '14	64817
17	Catch pan kit	83156
18	Hardware for mounting manifold, Spirit '13	69843
18	Catch pan holder, Spirit 300, '13	69806
19	Match holder w/chain	69894
20	Hardware, ignition module assembly (Hardware bag D)	84686
20	Ignition module, Spirit 220/320, Spirit '13	69849
20	Electronic igniter kit, Spirit 220-330	69851
21	Set of control knobs, Spirit 300, '13	69893
22	Electronic ignition switch/button, Spirit '13	69871
22	Electronic igniter kit, Spirit 220-330	69851
23	Hardware, control panel assembly, Spirit 300 (Hardware bag J)	84691
23	Control panel, Spirit 300, black, export '14	64829
24	Front cross piece, Spirit 300, '13	69831
24	Hardware, frame assembly (Hardware bag B)	84684
25	Hardware for door assembly, Spirit 210/310/320, export '14	83656
25	Door assembly, Spirit 300, black, export '14	64831

26	Door handle w/hardware, Spirit '13	69847
27	Hardware, lid assembly, Spirit '13	69844
28	Porcelain enamel cast iron cooking grates w/insert, GBS, Spirit 300	64812
29	Set of porcelain enameled flavorizer bars, Spirit 300, '13	69797
30	Hardware for fixed table, Spirit '13 (Hardware bag K)	69846
30	Fixed table, black, Spirit '13 - export	69872
31	Rear cross piece, Spirit 300, '13	69833
32	Hardware, frame assembly (Hardware bag B)	84684
32	Rear connectors, Spirit 300, set of 2	69814
33	Side burner valve w/gas line, 29mb	69885
34	Manifold assembly, Spirit 320, '13, 29mb	69776
34	Hardware for mounting manifold, Spirit '13	69843
35	Main gas line, Spirit '13	69841
36	Bulkhead assembly, G1/4", Spirit '13	69792
37	Not supplied by Weber	22222
38	Hardware, frame assembly (Hardware bag B)	84684
38	Magnet for door, Spirit '13	83320
38	RHS panel assembly, Spirit, export '14	64819
39	Grease tray, Spirit 300, '13	69804
40	Bottom panel, Spirit 300, '13, export	69812
40	Hardware, frame assembly (Hardware bag B)	84684
41	Tank brackets (snap-in) Spirit '09, export	91414
42	Hardware, caster assembly (Hardware bag A)	84683
42	Fixed caster w/plate - qty. 2	69827
43	Locking caster w/plate - qty. 2	69828
43	Hardware, caster assembly (Hardware bag A)	84683
410	Assembly guide, Spirit 310/320 Original, C E '14	58330
410	Assembly guide, Spirit 310/320 Original, C EU '14	58310
410	Literature Kit, Spirit 210/310/320 Original, export '14	57393

410	Literature Kit, Spirit Original 210/220/320 w/GBS LP, C EU	48959
410	Assembly guide, Spirit 310/320 Original, C E '14	58335
410	Brochure, Gourmet Barbecue System	56232
470	Hardware for side burner tray, Spirit '13	69897
470	Hardware kit, Spirit 320 Original, export '14	83651
470	Hardware, lid assembly, Spirit '13	69844
470	Hardware, control panel assembly, Spirit 300 (Hardware bag J)	84691
470	Hardware, ignition module assembly (Hardware bag D)	84686
470	Hardware for door assembly, Spirit 210/310/320, export '14	83656
470	Hardware, caster assembly (Hardware bag A)	84683
470	Hardware, black side burner assembly	84694
470	Hardware, fixed table assembly (Hardware bag K)	84692
470	Hardware, frame assembly (Hardware bag B)	84684
470	Hardware for mounting manifold, Spirit '13	69843
470	Hardware for fixed table, Spirit '13 (Hardware bag K)	69846

107 Items Found

[SCROLL TO TOP](#)

[View All](#)